**CHONRY** 创锐

# WP310 series PRODUCT DESCRIPTION OEM peristaltic pump series



## **CHONRY** 创锐

# WP310 series PRODUCT DESCRIPTION

## **OEM Peristaltic Pump**

Used in dishwashers, fermentation tanks environmental protection equipment

Max flow 1100mL/min Max speed 300rpm



### WP310 Series Peristaltic Pump

The pump head is designed with a transparent flip cover and two rollers, which can easily see the working condition of the pump. Suitable for 7 kinds of hoses, matching stepper motor, DC motor, synchronous motor, to meet a variety of scenarios and applications, can provide up to 1100mL/min flow.

### Transparent clamshell design

Easy to observe the condition of the hose

# The pump head is made of PPS+PC material

Corrosion resistant and high strength

#### Adaptive spring tube card

Reduce hose wear Longer life, wider adaptation



#### Small volume and large flow

Small size, compact structure, stable transmission


#### **Roller POM material**

Excellent heat resistance, wear resistance and stability

## Suitable for various types of hoses and power configurations

Support OEM customization

Pump Head	Channels	Rollers	Max Speed (rpm)	Hose Specifications (Id* Wall Thickness)mm	Max Flow (mL/min)
WP310	1	2	300	13# / 0.8X1.6	1100
				14# / 1.6X1.6	
				19# / 2.4X1.6	
				16# / 3.2X1.6	
				25# / 4.8X1.6	
				17# / 6.4X1.6	
				18# / 7.9X1.6	







Note: The test environment for flow data is normal temperature and pressure, and the test fluid is water. The values are for reference only, please refer to the actual situation.

### Schematic diagram of structure and function

 $\mathsf{Pump}\ \mathsf{head}\ \rightarrow\ \mathsf{Pump}\ \mathsf{head}\ \rightarrow\ \mathsf{Matching}\ \mathsf{motor}$ 





### Hose Installation Diagram

- Only touch the inner wall of the hose during fluid transfer, high hygiene level
- Compact structure design, stable transmission performance

#### **Display before installation**

• Adaptive tube clips, easy tube loading

#### **Display after installation**

• Transparent clamshell design for easy observation





Open the transparent flip cover, press the left self-adaptive tube clip, insert the adaptable hose, turn the roller clockwise, press the other side of the tube into the tube clip, and press down to close the flip cover.

## CHONRY 创锐

Baoding Chuangrui Precision Pump Co.,Ltd.

Address: NO.369 of HuiYang Street , Baoding 071000 , Hebei , China Mobile: +86 15633705132 Website: http://www.crpump.com Email: support@crpump.com